

The **Handy**




OPERATOR'S MANUAL AND PARTS LIST **Eco Walk-behind Spreader- THEDS**

Sales & Helpline 01793 333212

www.thehandy.co.uk

Before use please read & understand this manual, paying particular attention to the safety instructions.


Fig.1



LAYOUT(Fig.1)

- 1.Handle
- 2.Regulator
- 3.Material Container
- 4.Wheel

ASSEMBLY Fig.2



OPERATION

Any dispersible material can be evenly spread . Before filling with the material to be sown, first set the regulator lever to position 0, then select the desired spreading amount on the regulator scale.

CLEANING AND MAINTENANCE

Rinse your spreader with water after each use and allow it to dry completely.

Spreading Material Table


Spreading Material	1	2	3	4	5	6	7	8	9	10
Grass fertilizer				•						
Moss Killer					•					
Universal fertilizer			•							
Weed killer			•							
Grass nutrients				•						
Sand and salt	depending on grain size									

NOTE

The recommendations on the spreading material table are because of the different grain sizes of fertilizer and seed. These are only estimates, the appropriate spreader settings may vary depending on the material used. For other types of fertilizer or sand and grit, choose a setting to suit your needs.

Please do not spread any unslaked lime.

Parts Diagram



Parts List

No.	Handy no.	Part	Qty
1	TH190-1	Upper Handle Section	1
2	TH190-2	Lower Haddle Section	2
3	TH190-3	Control Handle	1
4	TH190-4	Bolt	2
5	TH190-5	Metal Plate	1
6	TH190-6	Adjustment Plate	1
7	TH190-7	Hopper	1
8	TH190-8	Wheel	2
9	TH190-9	Fixing	2
10	TH190-10	Axle	2
11	TH190-11	Impellar	1

WARRANTY

This appliance is guaranteed for 2 years from the date of purchase. It has been carefully produced and meticulously checked before delivery. The warranty covers only material or manufacturing faults, not normal wear or damage to fragile parts such as switches. The appliance is intended solely for private, not commercial use. If this product has been subjected to improper or inappropriate handling, abuse, or interventions not carried out by one of our authorised sales and service outlets, the warranty will be considered void. This warranty does not affect your statutory rights.

To order spare parts and see the complete range of garden machinery and garden equipment from Handy, visit:

www.thehandy.co.uk

Spares & Support: 01793 333212

