





## Pruner Attachment (THPATT)



No	Part No	Description	Qty
1	TH129-1	Oil Filler Cap	1
3	TH129-3	Fuel Tank Assy	1
4	TH129-4	Chain Hp-166	1
5	TH129-5	Chain Bar	1
6	TH129-6	Chian Bar Cover	1
7	TH129-7	Nut	1
8	TH129-8	Chian Cover	1
9	TH129-9	Chain Tension Adjuster Assy	1




## Brush Cutter Attachment (THBCATT)



No	Part No	Description	Qty
1	TH130-1	Shield	1
2	TH130-2	Flat Washer	3
3	TH130-3	Spring Washer	3
4	TH130-4	Screw	3
5	TH130-5	Blade Boss Outer	1
6	TH130-6	Nut Cover	1
7	TH130-7	Lock Nut (Left Hand)	1
8	TH130-8	Blade boss Inner	1




## Line Trimmer Attachment (THLTATT)



No	Part No	Description	Qty
2	TH131-2	Bracket	1
3	TH131-3	Screw	1
4	TH131-4	Nut	1
6	TH131-6	Spool & Cap Assy	1
7	TH131-7	Shield	1
8	TH131-8	Knob	1
9	TH131-9	Washer	1





## Hedge Trimmer Attachment (THHCATT-A)



No.	Part No.	Description	Qty.
1	TH185-1	Shaft assembly	1
2	TH185-2	Hexagon socket bolt	1
3	TH185-3	Flat washer	1
4	TH185-4	Spring washer	1
5	TH185-5	Hexagon socket bolt & spring washer	1
6	TH185-6	Hedge trimmer head	1
7	TH185-7	Blade cover	1
8	TH185-8	End clamp	1




## Multi-Cutter Shaft & D.Handle



No	Part No	Description	Qty
1	TH142-1	Hand Wheel	1
2	TH142-2	Coupling	1
3	TH142-3	Throttle Lock	1
4	TH142-4	Throttle Trigger	1
5	TH142-5	Handle Left Side	1
6	TH142-6	Handle Right Side	1
7	TH142-7	Safety Throttle Trigger	1
8	TH142-8	On/Off Switch	1
9	TH142-9	D.Handle	1



## Multi-Tool Engine Parts (THMC-A)





## Multi-Tool Engine Parts (THMC-A)

No	Part No	Description	Qty	No	Part No	Description	Qty
1	TH132-1	Screw	2	25	TH132-25	Flat Washer	2
2	TH132-2	Spring Washer	2	26	TH132-26	Heat Shield	1
3	TH132-3	Flat Washer	2	27	TH132-27	Exhaust	1
4	TH132-4	Filter Housing	1	28	TH132-28	Exhaust Gasket	1
5	TH132-5	Carburettor	1	29	TH132-29	Clips	1
6	TH132-6	Gasket	1	30	TH132-30	Screw	3
7	TH132-7	Screw	2	31	TH132-31	Spring Washer	3
8	TH132-8	Spring Washer	2	32	TH132-32	Flat Washer	3
9	TH132-9	Flat Washer	2	33	TH132-33	Fuel Tank	1
10	TH132-10	Insulator	1	34	TH132-34	Fly Wheel Key	1
11	TH132-11	Gasket	1	35	TH132-35	Fly Wheel	1
12	TH132-12	Spark Plug (ngk bpmr7a)	1	36	TH132-36	Nut	1
13	TH132-13	Engine Cowl	1	37	TH132-37	Spring	2
14	TH132-14	Flat Washer	1	38	TH132-38	Clutch Shoes (Pair)	1
15	TH132-15	Spring Washer	1	39	TH132-39	Washer	2
16	TH132-16	Screw	1	40	TH132-40	Bolt	2
17	TH132-17	Short Engine	1	41	TH132-41	Clutch Drum	1
18	TH132-18	Starter Pawl	1	42	TH132-42	Cir Clip	1
19	TH132-19	Recoil Assy	1	43	TH132-43	Bearing	1
20	TH132-20	Flat Washer	4	44	TH132-44	Screw	2
21	TH132-21	Spring Washer	4	45	TH132-45	Spring Washer	2
22	TH132-22	Screw	4	46	TH132-46	Flat Washer	2
23	TH132-23	Screw	2	47	TH132-47	Coil	1
24	TH132-24	Spring Washer	2				