




Item	Part No.	Description
1	PSI1000.01	Socket
2	PSI1000.02	Indicator Light
3	PSI1000.03	Switch, Power Rocker
4	PSI1000.04	Rd Head S/T Screw M3 x 6mm Black
5	PSI600.05	Front Panel
6	PSI600.V2-06	Lower Panel
7	PSI600.V2-07	Upper Panel
8	PSI800.08	Side Cover

Item	Part No.	Description
9	PSI600.V2-09	Fan
10	PSI600.V2-10	Fan Cover
11	PSI600.V2-11	Screw
13	PSI600.13	Terminal, Positive
14	PSI600.14	Terminal, Negative
15	PSI600.V2-15	Circuit Board
16	PSI600.V2-16	USB Port
--	PSI600.V2-F	Fuse (Not Shown)

NOTE: It is our policy to continually improve products and as such we reserve the right to alter data, specifications and component parts without prior notice. There may be alternative versions of this product, please contact us should you require this information.

IMPORTANT: No liability is accepted for incorrect use of product. Spare parts must be fitted by a competent person

WARRANTY: Guarantee is 12 months from purchase date, proof of which will be required for any claim.